





- Attaches directly to the mast (Magnetic plate)
- Not permanently fixed to the lift truck mast
- No tools, wiring or mechanical work required
- SkidLevel used two “D” batteries
- Battery life approx.. one year
- Reverse polarity protection
- No need to open enclosure
- **Installation time 15 seconds**
- Automatic calibration by pressing a button
- Visual LED indication when batteries needs replacement
- Visual LED indication when batteries are replaced
- Visual LED indication when system in automatic calibration mode
- Seven bright LED lights (red,orange and green)
- Can be moved to other lift trucks in seconds
- Works on all kinds of lift trucks
- System adapts to bent, uneven forks and uneven floor

### A RANGE OF SOLUTIONS TO SUIT YOUR MATERIAL HANDLING OPERATIONAL





MATERIAL HANDLING DEALER